


BASEBOARD COVERS- MEASURING GUIDE

WRCC
Wooden Radiator Cabinet Co.
P.O. Box 148037
Chicago, Illinois 60614-8037

Hints to help you measure:

When measuring for your cabinet, measure the height (H), the length (L) and the depth (D) of your heater. Include any pipes when measuring the length.



Please place your order online or submit by email, fax, or over the phone:
www.woodenradiatorcabinet.com
Phone: 800-817-9110
Fax: 773-281-1089
Email: wrc@radiatorcab.com

In many cases, baseboard heaters sit in front of the baseboard molding. In order to clear the trim, only the top of our covers extends to the wall beyond the depth of the end panels.



In the case of two baseboard units on perpendicular walls that meet in the corners, please contact us for instructions.

BASEBOARD PRICING GUIDE

The pricing below is based on steam/hot water baseboard heating systems. For electric baseboard heating systems, we will need to add \$30-50.

length	height	white	oak
3 ft	10 in	216	261
4 ft	10 in	250	295
5 ft	10 in	284	329
6 ft	10 in	319	364
7 ft	10 in	353	398

Standard/Custom Finishes

Shipping & Delivery via UPS

Baseboard covers shipped via United Parcel Service (UPS) are priced as follows (approximately)
Up to 6 feet - \$45; 6-12 feet - \$65; 12-18 feet - \$85

Please note that covers up to 8 feet in length are shipped with a solid, 1 piece top; 8-16 feet (L) covers will have a top in 2 pieces; covers exceeding 16 feet (L) will have a top in 3 pieces.